



HERKULES


Instrukcja montażu
Инструкция монтажа
Assembly guide

VALCOMP


www.valcomp.pl
tel. 22 818 77 22




1



2





3




4


L [mm]	1200	1500	1800	2000	2400
n	5	6	7	7	9




5



6



7



1:1